

QUICK•STEP® DOORMAT



Product description

The fitted doormat ensures a perfect finish. The mat has 3 cleaning zones and a dirt collection zone and provides maximum protection for your floor.

Content:

- 6 Screws and plugs
- Fitted doormat with 3 cleaning zones
- Prefab frame (can be used with all Quick-Step® laminate floors)

Packing Unit: 1

Dimensions:

- Frame: 478 x 790mm / 18.8 x 31.1 In. (external dimensions)
- Doormat: 434 x 746mm / 17.09 x 29.37 In. (Thickness: 9mm/ 0.35 In.)

Applications

Thanks to this fitted doormat, it's even more interesting to install Quick-Step® in the entry hall or the conservatory. The three cleaning zones ensure that all the dirt remains in the mat.



Characteristics

✓ Optimum protection of your Quick-Step® laminate floor

With the Quick-Step® Doormat at the entrance of your home, you can avoid unnecessary damage to your floor. The scraping zone of the mat loosens the dirt. Coarse dirt such as grit is already removed from shoes in this zone. This brushing zone removes all fine dirt (e.g. sand) which has been loosened in the scraping zone. The drying zone removes any moisture. This means your high-quality Quick-Step® laminate floor will look like new for years.

✓ Easy to clean

The Quick-Step® Doormat has collection zones for the removed dirt so you can easily clean the mat. You can shake out the mat, clean it with the vacuum cleaner or even with a high-pressure cleaner (max. 100°C/212°F).

✓ Easy to fit

The prefab frame can be used with all Quick-Step® laminate floors. The high-quality frame is designed to fit the dimensions of Quick-Step® floors, which makes installation even faster.

✓ Suitable for spaces with floor heating.

The Quick-Step® Doormat is suitable for spaces with floor heating.

✓ Does not obstruct the door from opening.

The thickness of the Quick-Step® Doormat perfectly matches the height of your floor, which means that the door is not obstructed when being opened. (The height is adjustable depending on the force with which the frame is attached to the subfloor.)



Instructions



1. First, install your floor (see installation instructions for Quick-Step® floors). If necessary, saw the planks of the floor to the correct length so that the prefab frame fits into the open space. Leave space for the recommended expansion joint so your floor can still expand.

(Tip: Leave a space of 468 by 780mm / 18.42 by 30.71 In)

2. Adjust the height under the frame depending on the floor and underlay thicknesses:

Floor thickness	Underlay thickness	Action
7 mm	2 mm	Cut and remove the underlay
	3 & 5 mm	Cut, remove the underlay and add 12 glue spots (1-2cm ³ each) with Quick-Step® One4all Glue : 3 on each side of the frame.
8 mm	2, 3 or 5 mm	
9,5 mm	2, 3 or 5 mm	Fix the frame through the underlay
12 mm	2, 3 or 5 mm	Keep the underlay and add a 2 mm thick shim measuring 450 x760 mm (i.e. Unisound)

3. Put the prefab frame in the floor opening and attach the frame to the subfloor with the supplied screws and plugs. The height is adjustable, depending on the force with which the frame is attached to the subfloor.
4. Place the Quick-Step® Doormat in the frame. It will not obstruct the door from opening.